

INSTALLATION GUIDE

GARLANDO **FOLDY** EVOLUTION FOOTBALL TABLE



Garlando

Leader in pool and football tables

MONKEY GAMESROOM

WWW.MONKEYGAMESROOM.CO.UK

WARNING, READ AND KEEP
This foosball table is not suitable for use by children under 3 years.
Small balls might be swallowed or inhaled.

Congratulations! You have purchased or about to purchase a quality football table / foosball table!

It is an indoor football table: please assemble it and use it indoors only.

IMPORTANT:

Once assembled, your foosball table is quite wide and may not fit through your doors. For this reason you should assemble it in the room you intend it to be used. Should you wish to move your table to another room, it might be necessary to remove its legs.

In order to ensure the foosball table has a long life and continued playing appeal, we recommend that you follow the instructions below:

Caution

Your foosball table has been manufactured for indoor playing only: do not leave it outdoors. Rain, snow and high humidity may damage its materials. Prolonged exposure to the sun is to be avoided too, due to its bleaching effects on the colours.

Standard cleaning

Clean your table periodically by rubbing its surfaces with a damp cloth to eliminate dust and other dirt residuals.

Deeper Cleaning

You can use any household detergent which does not contain wax or abrasives, having care to completely take it off.

Ammonia-based cleaners, scoring compounds, or solvents such as acetone, gasoline, etc. should absolutely be avoided, as these will damage the colours, especially those of the cabinet.

Do not flood the foosball table.

Playfield

The table has a plastic laminated playfield, beware not to wet the card below, which could wave.

Bars and bearings

Garlando roller bearings do not require any lubrication. However, should you wish to furtherly improve their smoothness, employ a good quality silicone spray, such as Garlando's proposal Slidy Spray, which has a lubricating and protective double action. Be careful not to use any vegetal or any other type of grease which may attract dirt and clog the roller bearings.

Using a spray is also useful to prolong the bar chromium-plating.

Use of protection cover

For a better protection from dust, especially if the foosball table is not used for a longtime, the use of the protection cover is advised.

Garlando does not accept any responsibility for damages resulting from disregarding these instructions.

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

Important:

Keep away the children during the assembly.
For safety reasons it is strongly recommended the football-table assembly by at least two adults.

UNPACKING

Lay the carton box on the floor. Note: the box label shows clearly the upper part. Cut the adhesive tapes and remove completely the carton top. Lower the sides of the box bottom: the foosball table is packed upside down (figure1).



(figure 1)

Remove the wooden panels for these are parts clamped inside the cabinet: they belong to the packing and they are of no use.



WARNING, READ AND KEEP
This foosball table is not suitable for use by children under 3 years.
Small balls might be swallowed or inhaled.

Inside the foosball table cabinet you will find a plastic bag containing:

- 2 ball entry fillers (figure 2),
- 8 plastic handles (figure 3),
- 16 roller bearings (figure 4),
- 8 end stop bushes (figure 5),
- 2 score counters (figure 6),
- 8 outside bearing retainers (figure 7),
- 16 inside bearing retainers (figure 8),
- 10 white plastic balls, and fixing screws

There is also another plastic bag containing the rods (included players and springs): four rods for each team: Goalkeeper – 1 player-rod, Defence – 2 player-rod, Forward – 3 player-rod, Midfielder – 5 player-rod



(figure 2)




(figure 3)



(figure 4)



(figure 5)



(figure 6)



(figure 7)



(figure 8)

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

Also inside the table you will find the following:

2 set of legs - 2 legs marked with the letter "D" and 2 legs marked with the letter "S" (figure 9)
2 crossbars (figure 11),
4 plastic feet (figure 12)



(figure 9)



(figure 10)



(figure 11)



(figure 12)


WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

There is also a plastic bag containing:

- 4 knobs with threaded shank (figure 13),
- 4 screws with washers and nuts (figure 14)
- 4 steel pins (figure 15),
- 4 cap nuts with washers (figure 16)
- 4 nylon disks (figure 17),
- 2 threaded bars (figure 18)



(figure 13)




(figure 14)



(figure 15)



(figure 16)




(figure 17)



(figure 18)

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

With the upturned football table take one couple of legs, the one marked with the letter D and the other one marked with the letter S and insert the steel pin into the blind hole for about 50% of its length using a hammer. (figure 19, 20, 21)




(figure 19)



(figure 20)



(figure 21)



(figure 22)


With the screws (inclusive of washers and nuts) and with the nylon disks (figure 22) assemble the leg and place the disk between leg and football-table side, tighten them with the supplied spanners.

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

Warning: before assembly continuation make sure that the holes on the legs and on the table side coincide in order to insert and screw the knob with threaded shank (figure 23). In case the holes do not coincide, it is necessary to assemble the leg marked with another letter.



(figure 23)




(figure 24)

Insert the knob with threaded shank (figure 25).
Fit in the crossbar into the leg grooves (fig. 26), make sure that the crossbar curve turns upward.



(figure 25)



(figure 26)

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

Screw a nut at the end of the threaded bar (figure 27) and insert it as illustrated in the figures 28, 29, 30.



(figure 27)



(figure 28)



(figure 29)



(figure 30)

Tighten strongly the nuts on the threaded bar using, on the one side, a pliers and, on the other side, the spanner 10mm (figure 30).

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

Repeat the assembly operation for the legs of the opposite side and insert the equipped plastic feet (figure 33).



(figure 31)



(figure 32)



(figure 33)



(figure 34)

We suggest you to put on the ball entry fillers before the rod assembly.

Insert manually the ball entry fillers (figure 35), insert and tighten the screws into the holes (figure 36). Do the same with the other ball entry filler.



(figure 35)



(figure 36)

WARNING, READ AND KEEP
This foosball table is not suitable for use by children under 3 years.
Small balls might be swallowed or inhaled.

The foosball table is equipped with 4 rods for each team:

Position A

Goalkeeper (1 player-rod): at the end of the playfield.

Position B

Defence (2 player-rod): in front of the same colour goalkeeper.

Position C

Mid-fielder (5 player-rod): in the middle of the playing field, in front of the 5-player rod of the opposite colour.

Position D

Forward (3 player-rod): in front of the 2 player-rod of the opposite colour. For example: the blue forward rod faces the red defence rod.

Start by placing the 1 player-rod and then all the others of the same colour following the above mentioned positions. Do the same for the other colour team.






Diagram Showing Aerial View of Final Assembly

The below diagram illustrates how the table should look once the installation is complete.



WARNING, READ AND KEEP
This foosball table is not suitable for use by children under 3 years.
Small balls might be swallowed or inhaled.



Beware !
When fixing the handle, make sure that you push it enough to cover the ridges completely

WARNING, READ AND KEEP
This foosball table is not suitable for use by children under 3 years.
Small balls might be swallowed or inhaled.

BEWARE NEW MODEL
Please follow these assembly instructions

Roller Bearing


This side of the bearing that must look towards the playfield
It is marked with the letters 'INT'



Outside Bearing Retainers



Inside Bearings Retainers



To match the two bearings, rest them on the bar while keeping them slanted so that the protruding male part "A" is in front of the female part "B", then bring them vertical by a slight pressure.



N.B. If you use an electric screw driver, set the torque at the minimum.

WARNING, READ AND KEEP

This foosball table is not suitable for use by children under 3 years.
Small balls might be swallowed or inhaled.

Caution:

Do not put on handles if the plastic feels cold. If this should be the case, warm them a little before installing them.

Start by manually inserting a handle onto the bar without covering the knurl (distinctly marked in figure 41). Delicately hammer it (figure 43) until the handle completely hides the knurl (figure 42).



(figure 41)



(figure 42)



(figure 43)

End assembly by fixing the score counters, making sure that at each side of the score counter color is the same as the goalkeeper (figure 44).



(figure 44)

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.

The football table is now ready for the play.
Have a good time! Do not forget to follow our care and maintenance advice.



(figure 45)

Put the table upright with the small wheels downwards.
Unscrew the knobs of the lower legs and screw them partially inside the cabinet (figure 46, 47, 48)



(figure 46)



(figure 47)



(figure 48)

WARNING, READ AND KEEP
This foosball table is not suitable for children under 3 years.
Small balls might be swallowed or inhaled.



WARNING, READ AND KEEP
This foosball table is not suitable for use by children under 3 years.
Small balls might be swallowed or inhaled.

FOOSBALL TABLE DEMOLITION AND HARMFUL MATERIAL REMOVAL

Demolition:

This foosball table does not require any particular care for the demolition as it does not contain any parts produced with dangerous materials.

The materials used are wood, MDF, steel, aluminium, ABS, PP (moplen), PE, PVC, plastic laminate.

The materials are present in the following parts:

Frame: wood, MDF, steel

Legs: wood, steel

Playfield: wood, plastic laminate.

Rods: steel, PP (moplen)

Accessories: ABS, PE, PVC

Finishing: aluminium, ABS.

During the football table demolition we suggest to separate the different materials and bring them to authorized collection centre for recycling.

Removal of harmful materials

The football-table does not contain or produce any harmful substances.



DICHIARAZIONE CE DI CONFORMITÀ

Il fabbricante: **GARLANDO S.r.l.**
Via Regione Piemonte, 5 - 15068 POZZOLO FORMIGARO (AL)

Dichiara che il giocattolo: **CALCIOBALLILLA mod. FOLDY**

è conforme alle disposizioni della direttiva sulla sicurezza dei giocattoli
(direttiva 88/378/CEE), e successivi emendamenti (direttiva 93/68/CEE);

Inoltre dichiara che sono state applicate le seguenti norme armonizzate:

UNI EN 71-1, UNI EN 71-2, UNI EN 71-3, EN 50088

Pozzolo Formigaro, il 01/10/2004

IL FABBRICANTE

Garlando s.r.l.

